

Getting Started with Your Amino 140 TV Box & Remote Control



1. Unpacking and Setting Up your Amino 140

2. Unbox Your Equipment:

- Carefully remove the Amino TV Box, remote control, power adapter, and any included cables from the packaging.

● Connect to Your TV:

○ HDMI Connection (Recommended):

- Connect one end of the HDMI cable to the HDMI port on the back of the Amino.
- Connect the other end to an available HDMI input on your TV.
- Ensure your TV is set to the correct HDMI input to display the Amino TV Box interface.

○ Alternative Connections:

- If your TV does not have an HDMI port, you can use the provided analog AV cables:
 - Connect the appropriate cables from the Amino TV Box to the corresponding inputs on your TV.
 - Set your TV to the correct input (e.g., AV, Component) to display the interface.

● Power Up:

- Connect the power adapter to the Amino TV Box and plug it into a power outlet.
 - Press the power button on the remote control to turn on the device.
 - **Network Connection:**
 - **Wired Connection (Recommended):**
 - Connect an Ethernet cable from your router to the Ethernet port on the back of the Amino TV Box.
-

Port Labels



Control

2. Using Remote

LuminetSM Television Equipment

Amino Willow Remote–LuminetSM Video Service Only



- **Power Button:**

- Turn the Amino TV Box on or off.
- #13 is power button for TV if remote is Program to TV

- **Navigation Buttons:**

- Use the arrow keys to move through menus.
- Press the **OK** button to select an option.

- **Guide Button:**

- Opens the TV program guide.

- **Menu Button:**

- Accesses the main menu for settings and features.
 - **Volume and Channel Controls:**
 - Adjust the volume and change channels using the respective buttons.
-

Watching Live TV

3. Accessing Live Television

- **Open the Program Guide:**
 - Press the **Guide** button on the remote.
 - **Select a Channel:**
 - Use the arrow keys to navigate through the list of available channels.
 - Highlight the desired channel and press **OK** to start watching.
-

Recording Programs

4. Quick Record

- **While Watching Live TV:**
 - Press the **Record** button  on the remote to start recording the current program.
 - A red dot will appear on the screen, indicating that recording is in progress.
- **From the Program Guide:**
 - Navigate to the program you wish to record.
 - Press the Record button  to schedule a recording.

5. Scheduling Future Recordings

- **Access the Program Guide:**
 - Press the **Guide** button on the remote.
 - **Select a Future Program:**
 - Use the arrow keys to navigate to the desired program.
 - Press the **Record** button (●) to schedule a recording.
 - **Series Recording:**
 - To record all episodes of a series, press the **Record** button (●) twice.
 - A double red dot will appear, indicating that series recording is enabled.
-

Playing Back Recordings

6. Accessing Recorded Programs

- **Open the DVR Menu:**
 - Press the **Menu** button on the remote.
 - Navigate to **DVR** and press **OK**.
- **Select a Recording:**
 - Choose **Recordings** to view a list of saved programs.
 - Highlight the desired program and press **OK** to start playback.

7. Playback Controls

- **Pause/Play:**
 - Press the **Pause** (⏸) button to pause playback.
 - Press the **Play** (▶) button to resume.
- **Fast Forward/Rewind:**
 - Use the **Fast Forward** (⏭) and **Rewind** (⏮) buttons to navigate through the recording.
 - Each press increases speed (e.g., 2x, 4x, 8x).
- **Stop:**
 - Press the **Stop** (■) button to end playback and return to the recordings list.

YouTube link for programming your amino 140 remote scan the QR code



TV Brands Code for Amino 140

TOSHIBA-3021	TCL-2856	SONY-2679
ONN-3663	INSIGNIA-1368	VIZIO-3211
SAMSUNG-2448	PANASONIC-2153	RCA-2351
LG-1628	PHILLIPS-2195	SHARP-2550
HISENSE 1249	SCEPTRE- 2498	